IP USER MANUAL:

1. Install & Configure Zoiper [After download Zoiper, please call **112(PABX)/ 2112(IP Phone)**]

2. IP Phone to IP Phone: just use IP Phone Ext (Exm: 2019 to 2123)

3. IP Phone to PABX: Dial "**7**"after getting IVR record just press PABX EXT (Exm:**7**…112)

4. To call outside (**RESTRICTED**) **[**Open by the order of Department Head**]**: Dial the number

[Exm: 01919…../031…]

PABX USER MANUAL:

1.PABX to IP Phone Ext. use "**9**" and press IP Phone Ext.(Exm: 9 and 2019)

2.PABX to outside :use "**9**" after ringing dial the number with adding an extra digit "**8**"

[Exm: **9**…**8**031…../**9**…**8**01919]